








No Desk/Plinth Hole(s)
(cable exits side of Switch)









Cable only Hole




12mm MDF top with recess
for Switch and cable Hole



18mm MDF top with recess
for Switch and cable Hole



Cable Hole



Switch Recess

N.B. Switch recess can be no more than 12mm deep